

SHARP®

LC-46G7M LC-52G7M

LCD COLOUR TELEVISION

液晶彩色電視機

液晶彩色电视机

OPERATION MANUAL

使用說明書

使用说明书

ENGLISH

中文(繁體)

中文(简体)

AQUOS



HDMI™
HIGH-DEFINITION MULTIMEDIA INTERFACE



Printed on 100% post-consumer recycled paper.

本說明用紙使用的是100%的再生紙。

本說明用紙使用的是100%的再生紙。

Printed in Japan

日本印刷

日本印刷

TINS-C642WJZZ ④

06P10-JA-KG

LC-46G7M LC-52G7M

LCD COLOUR TELEVISION ENGLISH

OPERATION MANUAL

Dear SHARP customer

Thank you for your purchase of the SHARP LCD colour TV product. To ensure safety and many years of trouble-free operation of your product, please read the Important Safety Precautions carefully before using this product.

Contents

Dear SHARP customer	1	Basic adjustment settings	18
Contents	1	Menu operation buttons	18
Trademarks	2	On-Screen Display	18
Important Safety Precautions	3	Menu items (TV/INPUT1-3)	19
Supplied accessories	4	Menu items (HDMI/DVI)	19
Preparation	5	Auto installation	20
Inserting the batteries	5	Programme setup	20
Using the remote control unit	5	Auto search	20
Cautions regarding remote control unit	5	Manual setting for each channel	21
Setting the TV	6	Search tuning	21
Setting the TV on the wall	7	Fine tuning	21
Removing the stand	7	Colour system	22
Protection against overturning	8	Sound system (Broadcasting system)	22
Basic connection	9	Labelling channels	22
Connecting to an antenna	9	Skipping channels	23
Connecting to the AC outlet	9	Setting the child lock	23
Connecting a VCR, game console or camcorder	10	Password setting for child lock (for TV	
Connecting a DVD player	10	input mode) See page 31.	
Connecting a Digital TV STB (Set Top Box)	11	Sort	23
Connecting a PC	11	Erase Programme	24
Part names	12	AV MODE selection	25
TV (Front)	12	OPC (Optical Picture Control) setting	25
TV (Rear)	13	Picture adjustments	26
Remote control unit	14	Advanced	27
Watching TV	15	Colour temperature	27
Turning on the power	15	Black	27
Turning off the power	15	Quick Shoot	27
Simple button operations for changing channels	15	3D-Y/C	27
Using Flashback (\$) on the remote control unit	16	Monochrome	28
Using MPX on the remote control unit	16	Film Mode	28
Simple button operation for changing		Range of OPC	28
volume/sound	17	Audio adjustment	29
Sleep timer	17	Surround	29
		Power Control	30

Contents

Useful adjustment settings	31	Using external equipment	42
Password setting for child lock (for TV input mode)	31	Displaying an external equipment image	42
Speaker Setup	32	Displaying a DVD image (Example)	42
Connecting external speakers	32	Input Select	42
External Audio Bypass	32	Useful features	43
Input Skip	33	Teletext function	43
Input Signal (PC input mode only)	33	Teletext language setting	45
Auto Sync. adjustment (PC input mode only)	34	Freezing images	45
Fine Sync. adjustment (PC input mode only)	34	Appendix	46
Input Label	35	Troubleshooting	46
Image position	35	RS-232C port specifications	47
Wide Screen Signalling (WSS)	36	PC compatibility chart	48
Picture aspect ratio	36	Specifications	49
Standby Mode	37	Optional accessories	49
Reset	37	Removing the speakers	50
WIDE mode (for TV/AV input mode)	38	Dimensional drawings	51
WIDE mode (for PC input mode)	39		
Audio Only	40		
DNR (Digital Noise Reduction)	40		
HDMI Setup	40		
Language setting for on-screen display	41		
Identification	41		
Colour system setting	41		

Trademarks

- “HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.”

Important Safety Precautions

- **Cleaning**—Unplug the AC cord from the AC outlet before cleaning the product. Use a damp cloth to clean the product. Do not use liquid cleaners or aerosol cleaners.




- **Water and moisture**—Do not use the product near water, such as bathtub, washbasin, kitchen sink, laundry tub, swimming pool and in a wet basement.



- **Do not place vases or any other water-filled containers on this product.** The water may spill onto the product causing fire or electric shock.




- **Stand**—Do not place the product on an unstable cart, stand, tripod or table. Doing so can cause the product to fall, resulting in serious personal injuries as well as damage to the product. Use only a cart, stand, tripod, bracket or table recommended by the manufacturer or sold with the product. When mounting the product on a wall, be sure to follow the manufacturer's instructions. Use only the mounting hardware recommended by the manufacturer.



- **When relocating the product** placed on a cart, it must be moved with utmost care. Sudden stops, excessive force and uneven floor surface can cause the product to fall from the cart.



- **Ventilation**—The vents and other openings in the cabinet are designed for ventilation. Do not cover or block these vents and openings since insufficient ventilation can cause overheating and/or shorten the life of the product. Do not place the product on a bed, sofa, rug or other similar surface, since they can block ventilation openings. This product is not designed for built-in installation; do not place the product in an enclosed place such as a bookcase or rack, unless proper ventilation is provided or the manufacturer's instructions are followed.




- The LCD panel used in this product is made of glass. Therefore, it can break when the product is struck forcefully or with a sharp object. If the LCD panel is broken, be careful not to be injured by broken glass.




- **Heat sources**—Keep the product away from heat sources such as radiators, heaters, stoves and other heat-generating products (including amplifiers).



- To prevent fire, never place any type of candle or naked flames on the top or near the TV set.



- To prevent fire or shock hazard, do not place the AC power cord under the TV set or other heavy items.




- Do not place heavy objects on this product or stand on it. Doing so could cause injury if the product overturns. Take special care near children and pets.



The LCD panel is a very high technology product with 6,220,880 thin film transistors, giving you fine picture details. Due to the very large number of pixels, occasionally a few non-active pixels may appear on the screen as a fixed point of blue, green or red. This is within product specifications and does not constitute a fault.

Precautions when transporting the TV

Be sure to always carry the TV by two people holding it with two hands—one hand on each side of the TV.













- Do not display a still picture for a long time, as this could cause an afterimage to remain.

- Install the product in a place where the AC cord can be easily unplugged from an AC outlet and the AC INPUT terminal on the rear of the product.

Supplied accessories

Make sure the following accessories are provided with the product.

Remote control unit	"AAA" size battery (×2)	AC cord
		
Page 14	Page 5	Page 6
Cable clamp (×2)	Cable clamp	Operation manual
		
Page 6	Page 6	
Safety restraints		
<div>     </div> <div> <div>Restraining brackets</div> <div>Screws for brackets</div> <div>Clamps</div> <div>Screws for clamps</div> </div> <div>Page 8</div>		

NOTE


- Always use the AC cord supplied with the TV.
- The illustrations and on-screen displays in this operation manual are for explanation purposes and may vary slightly from the actual operations.
- The illustrations used throughout this manual are based on LC-46G7M.

Preparation


Inserting the batteries

Before using the TV for the first time, insert two “AAA” size batteries (supplied). When the batteries become depleted and the remote control fails to operate, replace the batteries with new “AAA” size batteries.


1 Open the battery cover.



2 Insert two supplied “AAA” size batteries.



3 Close the battery cover.



- Place batteries with their terminals corresponding to the (+) and (–) indications in the battery compartment.

CAUTION


Improper use of batteries can result in chemical leakage or explosion. Be sure to follow the instructions below.

- Do not mix batteries of different types. Different types of batteries have different characteristics.
- Do not mix old and new batteries. Mixing old and new batteries can shorten the life of new batteries or cause chemical leakage in old batteries.
- Remove batteries as soon as they have worn out. Chemicals that leak from batteries can cause a rash. If you find any chemical leakage, wipe thoroughly with a cloth.
- The batteries supplied with this product may have a shorter life expectancy due to storage conditions.
- If you will not be using the remote control unit for an extended period of time, remove the batteries from it.

Using the remote control unit


Use the remote control unit by pointing it towards the remote sensor window.

Objects between the remote control unit and sensor window may prevent proper operation.



Cautions regarding remote control unit

- Do not subject the remote control unit to shock. In addition, do not soak the remote control unit with liquids, or place it in an area with high humidity.
- Do not install or place the remote control unit under direct sunlight. The heat may cause deformation of the unit.
- The remote control unit may not work properly if the remote sensor window of the TV is under direct sunlight or strong lighting. In such case, change the angle of the lighting or TV, or operate the remote control unit closer to the remote sensor window.



Setting the TV


Notes on installing the TV

- Avoid direct sunlight and place the TV in a well-ventilated location.
- Place the TV in a level location.

1

Removing the terminal cover



TV (rear view)



Press down the hooks to remove the cover toward you.

2

Connecting the AC cord, antenna, and external equipment to the TV



See pages 9 to 11 for connecting antennas and external equipment, such as VCR and DVD player.

AC outlet


AC cord

- Place the TV close to the AC outlet, and keep the power plug within reach.

3

Bundling the cables and closing the terminal cover

Insert the cable clamps in the holes on the TV as shown.



Preparation

Setting the TV on the wall

- You can mount the TV on the wall, using the optional AN-37AG2/AN-52AG1 bracket.
- For details, refer to the instructions supplied with the optional bracket.

CAUTION


- **This TV should be mounted on the wall only with the AN-37AG2/AN-52AG1 (SHARP) wall mount bracket. The use of other wall mount brackets may result in an unstable installation and may cause serious injuries.**
- **Installing the Liquid Crystal Television requires special skill that should only be performed by qualified service personnel. Customers should not attempt to do the work themselves. SHARP bears no responsibility for improper mounting or mounting that results in accident or injury.**

Using an optional bracket to mount the TV


- You can ask a qualified service personnel about using an optional AN-37AG2/AN-52AG1 bracket to mount the TV to the wall.
- Carefully read the instructions that come with the bracket before beginning work.

Hanging on the wall

AN-37AG2/AN-52AG1 wall mount bracket.
(See the bracket instructions for details.)



About setting the TV angle and height adjustment



For AN-52AG1

- | |
|--|
| ① 0°/5°/10°/15°/20°
for LC-46G7M
(0°/5°/10°/15° for
LC-52G7M) |
| ② -5/0/+5 cm
(can be moved 5
cm up or down) |

NOTE

- Detach the cable clamps on the rear of the TV when using the optional mount bracket.

Removing the stand

For wall mounting with the optional bracket, remove the stand.


Before attaching/detaching the stand

- Before detaching (or attaching) the stand, unplug the AC cord from the AC outlet.
- Remove all terminal covers and connected cables.
- Make sure two or more people perform the operation.

CAUTION


- **Do not remove the stand from the TV unless using an optional bracket to mount it.**

1



Unfasten the four screws used to secure the stand in place.

2



Detach the stand from the TV.
(Hold the stand so it will not drop from the edge of the base area.)

NOTE

- To attach the stand, perform the above steps in reverse order.

Preparation

Protection against overturning

There is a danger of the product overturning in the case of a disaster or sudden collision. Carry out the following tip-resistant measurement for your safety.

Anchoring the TV to the wall or a pillar


1

Fix the product with the 2 clamps (supplied), using the screws (supplied).

2


Fix the TV to the wall using extra strong ties (commercially available).

View from the top




Fixing the TV to the table

1



Place the TV onto a table. Attach the two supplied restraining brackets to the stand with the four supplied screws.

2



Insert commercially available screws in the holes of the restraining brackets from the top and tighten the screws to secure the TV to the table.

- Use commercially available screws of the proper size to firmly secure the TV.

CAUTION

- As this product is heavy, use a table that is wide enough to support the product and capable of withstanding the product's weight. The table should be set where it will not be overturned.
- Be sure to use at least two people when moving the TV.


Preparation

Simple operations for watching a TV programme


Basic connection

Connecting to an antenna

To enjoy a clearer picture, use an outdoor antenna. The following is a brief explanation of the types of connections that are used for coaxial cable.



Connecting to the AC outlet



NOTE

- Always turn off the power of the TV when connecting the AC cord.
- Disconnect the AC cord from the AC outlet if the TV will not be used for a long period of time.

Preparation

You can connect many types of external equipment to your TV, like a VCR, DVD player, HDTV tuner, game console and camcorder. To view external source images, select the input source from **TV/VIDEO** on the remote control unit or **TV/VIDEO** on the TV.


CAUTION

- To protect all equipment, always turn off the TV before connecting to a VCR, DVD player, HDTV tuner, game console, camcorder or other external equipment.
- Please refer to the relevant operation manual (VCR, DVD player, etc.) carefully before making connections.


Connecting a VCR, game console or camcorder

A VCR, game console, camcorder and some other audiovisual equipment can be conveniently connected using the INPUT 3 terminals.

When using S-VIDEO cable (commercially available).



When using composite cable (commercially available).



NOTE

- When the S-video terminal and video terminals are both used, the S-video input takes priority over the video terminals only when "Auto" is selected in "Input Select" setting.
- You can also connect the game console to INPUT 1 or 2 terminals to enjoy clearer picture.


Connecting a DVD player

You can use the INPUT 1/INPUT 2 (component) or INPUT 4/INPUT 5 (HDMI) terminal when connecting to a DVD player and other audiovisual equipment.


NOTE

- When using a DVI-HDMI conversion adaptor, input the Audio Signal from the AUDIO terminal of INPUT 5.
- When using component cable, select "COMPONENT" for "Input Select" in the menu.

When using HDMI cable (commercially available).



When using component cable (commercially available).



Preparation


Connecting a Digital TV STB (Set Top Box)

You can use the INPUT 1/INPUT 2 (component) or INPUT 4/INPUT 5 (HDMI) terminal when connecting to a Digital TV STB and other audiovisual equipment.


NOTE

- When using a DVI-HDMI conversion adaptor, input the Audio Signal from the AUDIO terminal of INPUT 5.
- When using component cable, select "COMPONENT" for "Input Select" in the menu.

When using HDMI cable (commercially available).




When using component cable (commercially available).



Connecting a PC



You can use the INPUT 6 (DVI) terminal when connecting to a PC.

When using DVI cable (commercially available).



Part names

TV (Front)



*OPC: Optical Picture Control
(See page 25.)


Regarding the headphone jack

- Use headphones with a stereo mini plug (Ø 3.5 mm).
- Be sure to unplug headphones from the jack when they are not in use.
- The speakers do not output volume when headphones are plugged in.
- Audio adjustments (page 29) do not affect the audio of connected headphones.
- You can set the volume to different levels for each input source.


Volume display when headphones are plugged in



TV (Rear)



Remote control unit



NOTE

- When using the remote control unit, point it at the TV.

- 1 **POWER (STANDBY/ON)**
To switch the power on and off. (See page 15.)
- 2 **0 - 9**
Set the channel. (See page 15.)
TELETEXT mode: Set the page. (See pages 15, 43 and 44.)
- 3 **⏮ (Flashback)**
Press to return to the previous image in normal viewing mode. (See page 16.)
- 4 **WIDE**
Change the wide image mode. (See pages 38 and 39.)


- 5 **AV MODE**
Select a video setting. (See page 25.)
- 6 **MPX**
Select the sound multiplex mode. (See page 16.)
- 7 **VOL + / VOL -**
Set the volume. (See page 17.)
- 8 **🔇 (Mute)**
Mute the sound. (See page 17.)
- 9 **INPUT4 (HDMI)**
Directly select and output the signal from the INPUT4 terminal. (See page 42.)
INPUT5 (HDMI)
Directly select and output the signal from the INPUT5 terminal. (See page 42.)
- 10 **SURROUND**
Select Surround settings. (See page 29.)
- 11 **EXIT**
Turn off the On Screen Display.
- 12 **☰ (TELETEXT)**
Select the TELETEXT mode. (all TV image, all TEXT image, TV/TEXT image) (See pages 43 and 44.)
⏮ (Reveal hidden for TELETEXT)
TELETEXT mode: Display hidden characters. (See page 43.)
🗨 (SUBTITLE for TELETEXT)
To turn the subtitles on and off. (See page 44.)
⏮ (Hold)
TELETEXT mode: Stop updating Teletext pages automatically. Press ⏮ again to release the hold mode. (See page 43.)
⏮ (Subpage)
Display the Teletext subpage directly. (See page 44.)
⏮ (Top/Bottom/Full)
TELETEXT mode: Set the area of magnification. (See page 43.)
- 13 **TV/VIDEO (INPUT SOURCE)**
Select an input source. (TV, INPUT 1, INPUT 2, INPUT 3, INPUT 4, INPUT 5, INPUT 6) (See pages 10, 35 and 42.)
- 14 **OPC**
To switch the Optical Picture Control on and off. (See page 25.)
- 15 **FREEZE**
Freeze a motion picture on the screen. (See page 45.)
- 16 **DISPLAY**
Display the programme information.
TELETEXT mode: Display the time information included in the Teletext broadcast. (See page 44.)
- 17 **CH / CH V**
TV input mode: Select the channel. (See page 15.)
TELETEXT mode: Select the page. (See pages 43 and 44.)
- 18 **SLEEP**
Set the Sleep timer. (See page 17.)
- 19 **MENU**
Display the menu screen. (See page 18.)
- 20 **▲ / ▼ / ◀ / ▶ (Cursor)**
Select a desired item on the setting screen. (See page 18.)
ENTER
Execute a command. (See page 18.)
- 21 **RETURN**
MENU mode: Return to the previous menu screen. (See page 18.)
- 22 **Colour (Red/Green/Yellow/Blue)**
TELETEXT mode: Select a page. (See page 43.)

Watching TV

Turning on the power

Press **POWER** on the TV.

- POWER indicator (Green): The TV is on. (After a few seconds, an image appears with sound.)
- After turning the power "ON" by pressing **POWER** on the TV, you can turn the power ON/OFF by pressing **POWER** on the remote control.



Turning off the power

Press **POWER** on the remote control.

- The TV enters standby mode and the image on the screen disappears.
- The POWER indicator on the TV changes from green to red.

Press **POWER** on the TV.

- The POWER indicator on the TV turns off.
- When the TV is turned off by **POWER** on the TV, you cannot turn on the power by pressing **POWER** on the remote control.


POWER indicator

Off	Power off
Red	The TV is in standby mode.
Green	The TV is on.

NOTE

- If you are not going to use this TV for a long period of time, be sure to remove the AC cord from the AC outlet.
- Minor power is consumed when the TV is turned off by **POWER** on the TV or when the TV is in standby mode.

POWER button




Simple button operations for changing channels

You can change channels in several ways.


Using CH ^/V on the remote control unit

- Press **CH ^** to increase the channel number.
- Press **CH V** to decrease the channel number.




NOTE

- **CH ^/V** on the TV operates the same as **CH ^/V** on the remote control unit.



Using 0 – 9 on the remote control unit

Select the channels directly by pressing buttons **0** to **9**.



EXAMPLE

To select a 1-digit channel (e.g. channel 2):

- Press **0**, followed by **2**.


To select a 2-digit channel (e.g. channel 12):

- Press **1**, followed by **2**.

When viewing Teletext information

View a page directly which is 3-digit page number from 100 to 899 by pressing buttons **0** to **9**.

Using Flashback (↶) on the remote control unit




Press **↶** to switch the currently tuned channel to the previously tuned channel.
Press **↶** again to switch back to the currently tuned channel.

Press **↶** to toggle between the currently selected input source and the previously selected one.

Press **↶** to return to the previous page in TELETEXT mode.

Using MPX on the remote control unit




In the NICAM TV broadcasts

When receiving a stereo signal

Each time you press **MPX**, the mode switches between NICAM STEREO and MONO.


Stereo mode



When receiving a bilingual signal

Each time you press **MPX**, the mode switches among NICAM CH A, NICAM CH B, NICAM CH AB and MONO.

Bilingual mode



When receiving a monaural signal

Each time you press **MPX**, the mode switches between NICAM MONO and MONO.

Monaural mode




In the TV mode of A2 TV broadcasts

When receiving a stereo signal

Each time you press **MPX**, the mode switches between STEREO and MONO.


Stereo mode



When receiving a bilingual signal

Each time you press **MPX**, the mode switches among CH A, CH B and CH AB.


Bilingual mode



When receiving a monaural signal

When you press **MPX**, "MONO" displays.


Monaural mode



NOTE

- "BBC2", "99" and "PAL" are tentative network name, channel and colour system.

Simple button operation for changing volume/sound



Changing the volume

You can change the volume on the TV or on the remote control unit.

- To increase the volume, press **VOL +**.
- To decrease the volume, press **VOL -**.



 NOTE

- “TV”, “INPUT1”, “INPUT2”, “INPUT3”, “INPUT4”, “INPUT5” and “INPUT6” modes can store volume adjustment values separately.

Using Mute (🔇) on the remote control unit

✖ mutes the current sound output.

1



Press $\frac{1}{4}$.

- The sound is silenced.
- “~~Call~~” has been displayed on the screen for 30 minutes.

Mute



 NOTE

- Within 30 minutes after pressing , press one of the buttons below to cancel the mute.
—VOL - /VOL +
—
- **Mute will be cancelled after 30 minutes. However, the TV will not suddenly output loud sound as the volume level will be set to 0 automatically. Increase the volume level by pressing VOL +.**

2

Press again within 30 minutes to cancel the mute.

- Before 30 minutes, the volume level returns to the previous setting.

Sleep timer

Allows you to set a time when the TV automatically switches to standby.

1

Press **SLEEP**.

- Remaining time displays when sleep timer has been set.

Sleep Timer: Remain 2 hr. 00 min.

2

Each time you press **SLEEP**, the remaining time switches as shown below.

0 hr. 30 min. → 1 hr. 00 min. → 1 hr. 30 min.
↑ ↓
Off ← 2 hr. 30 min. ← 2 hr. 00 min.


 NOTE

- The sleep timer indicator on the TV lights up when the time has been set.
- When the time has been set, countdown automatically starts.
- Five minutes before the preset of time expires, the remaining time displays each minute.
- Select "Off" by pressing **SLEEP** to cancel the sleep timer.

Basic adjustment settings


Menu operation buttons

Use the following buttons on the remote control to operate the menu.



On-Screen Display

(Example)



- ① Item displayed in yellow
 - This indicates the item currently selected.
 - Press **ENTER** to go to the adjustment screen for this item.
- ② Item in brackets
 - This indicates the current setting for the item.
- ③ Item displayed in white
 - This indicates an item can be selected.
- ④ Item displayed in grey
 - This indicates that the item cannot be selected.
 - *There are various reasons why items cannot be selected, but the main reasons are as follows:
 1. Nothing is connected to the selected input terminal.
 2. The function is not compatible with the current input signal.

NOTE

- Menu options differ in the selected input modes, but the operating procedures are the same.
- The screens in the operation manual are for explanation purposes (some are enlarged, others cropped) and may vary slightly from the actual screens.

MENU: Press to open or close the menu screen.

▲/▼/◀/▶: Press to select a desired item on the screen or adjust a selected item.

ENTER: Press to go to the next step or complete the setting.

RETURN: Press to return to the previous step.

◀▶: Select ENTER: Enter RETURN: Back MENU: End

The bar above is an operational guide for the remote control. The bar will change in accordance with each menu setting screen.

Menu items (TV/INPUT1-3)


List of menu items to help you with operations




OPC	Page 25
Backlight	Page 26
Contrast	Page 26
Brightness	Page 26
Colour	Page 26
Tint	Page 26
Sharpness	Page 26
Advanced	
Colour Temp.	Page 27
Black	Page 27
Quick Shoot	Page 27
3D-Y/C	Page 27
Monochrome	Page 28
Film Mode	Page 28
Range of OPC	Page 28




Treble	Page 29
Bass	Page 29
Balance	Page 29
Surround	Page 29



No Signal Off	Page 30
No Operation Off	Page 30



Auto Installation	Page 20
Programme Setup	Pages 20-24
Child Lock	Page 31
Speaker Setup	Page 32
Input Skip	Page 33
Input Label	Page 35
Position	Page 35
WSS	Page 36
4:3 Mode	Page 36
Standby Mode	Page 37
Language	Page 41
Text Language	Page 45
Identification	Page 41
Reset	Page 37



Audio Only	Page 40
DNR	Page 40
Input Select	Page 42
Colour System	Page 41

Menu items (HDMI/DVI)

List of menu items to help you with operations




OPC	Page 25
Backlight	Page 26
Contrast	Page 26
Brightness	Page 26
Colour	Page 26
Tint	Page 26
Sharpness	Page 26
Advanced	
Colour Temp.	Page 27
Black	Page 27
Quick Shoot	Page 27
Monochrome	Page 28
Film Mode	Page 28
Range of OPC	Page 28




Treble	Page 29
Bass	Page 29
Balance	Page 29
Surround	Page 29



No Signal Off	Page 30
No Operation Off	Page 30



Speaker Setup	Page 32
Input Skip	Page 33
Input Signal	Page 33
Auto Sync.	Page 34
Input Label	Page 35
Fine Sync.	Page 34
Position	Page 35
Standby Mode	Page 37
Language	Page 41
Reset	Page 37



Audio Only	Page 40
DNR	Page 40
Input Select	Page 42
HDMI Setup	Page 40


NOTE

- Some menu items may not be displayed depending on the selected input source.

Basic adjustment settings

Auto installation


You can run auto installation again, even after setting up the preset channels.



1 Press **MENU** and the MENU screen displays.


2 Press **◀/▶** to select “Setup”.

3 Press **▲/▼** to select “Auto Installation”, and then press **ENTER**.



4 If you have already set the password, enter it here.

- See page 31 for setting a password.



5 Press **◀/▶** to select “Yes”, and then press **ENTER**.

6 Press **▲/▼** to select the desired language listed on the screen, and then press **ENTER**. After this setting, auto search starts with the following order.

- ① Programme auto search
- ② Auto labelling
- ③ Auto sorting

You do not need to do anything during the auto search.

NOTE

- After performing step 6, the menu screen shown in step 3 will reappear. Do not turn off the TV before then, because the TV is saving the data found.

Programme setup

You can run the auto search procedure again at any time by accessing the Setup menu and Programme Setup. Channels can be tuned automatically or manually.

Auto search

You can also automatically search by performing the procedure below. This is the same function as programme auto search in auto installation.


1 Press **MENU** and the MENU screen displays.

2 Press **◀/▶** to select “Setup”.

3 Press **▲/▼** to select “Programme Setup”, and then press **ENTER**.

If you have already set the password, enter it here.

- See page 31 for setting a password.



4 Press **▲/▼** to select “Auto Search”, and then press **ENTER**.

5 Press **◀/▶** to select “Yes”, and then press **ENTER**.

- Auto search starts with the following order.
 - ① Programme auto search
 - ② Auto labelling
 - ③ Auto sorting

NOTE

- After performing step 5, the menu screen shown in step 3 will reappear. Do not turn off the TV before then, because the TV is saving the data found.

Basic adjustment settings

Manual setting for each channel

You can set some channel items manually. They are Search, Fine (TV frequency), Colour sys., Sound sys., Label (Network name), Skip and Lock (Child Lock).

1 Press **MENU** and the MENU screen displays.

2 Press **◀/▶** to select "Setup".

3 Press **▲/▼** to select "Programme Setup", and then press **ENTER**.
If you have already set the password, enter it here.
• See page 31 for setting a password.

4 Press **▲/▼** to select "Manual Adjust", and then press **ENTER**.

5 Press **◀/▶** to select "Yes", and then press **ENTER**.

Programme Setup "Manual Adjust" menu

01 SAT.1	02 PR07	03 KABEL		

Next

You can select one of the following settings.

- ① **Search** (See page 21.)
- ② **Fine** (See page 21.)
- ③ **Colour system** (See page 22.)
- ④ **Sound system** (See page 22.)
- ⑤ **Label** (See page 22.)
- ⑥ **Skip** (See page 23.)
- ⑦ **Lock** (See page 23.)

Search tuning

1 Press **▲/▼/◀/▶** to select the channel you want to edit, and then press **ENTER**.
• The selected channel information displays.

2 Press **▲/▼** to select "Search", and then press **ENTER**.

MENU [Setup ... Programme Setup]	
Search	
Fine [179.25]	179.25 MHz
Colour sys. [Auto]	Next
Sound sys. [B/G]	Store
Label [SAT.1]	Cancel
Skip [Off]	
Lock [Off]	

3 Press **▲/▼** to select item and press **ENTER**.
• **Next**: Search the next channel.
• **Store**: Memorise the current display channel.
• **Cancel**: Return to the previous screen. (The search result will not be stored.)

Fine tuning

1 Press **▲/▼/◀/▶** to select the channel you want to edit, and then press **ENTER**.
• The selected channel information displays.

2 Press **▲/▼** to select "Fine", and then press **ENTER**.

3 Press **◀/▶** to adjust the frequency, and then press **ENTER**.
• Adjust while checking the background picture as a reference.

Search	
Fine [179.25]	179.25 MHz
Colour sys. [Auto]	
Sound sys. [B/G]	
Label [SAT.1]	
Skip [Off]	
Lock [Off]	

- Instead of the method above, you can also set by directly entering the frequency number of the channel with **0 – 9**.
- When setting a frequency on the "Fine" screen, the last figure of the frequency needs to be "0" or "5".

EXAMPLE

- 179.25 MHz: Press **1 → 7 → 9 → 2 → 5**.
- 49.25 MHz: Press **4 → 9 → 2 → 5 → ENTER**.

Basic adjustment settings

Manual setting for each channel (continued)

Colour system

1

Press **▲/▼/◀/▶** to select the channel you want to edit, and then press **ENTER**.

- The selected channel information displays.

2

Press **▲/▼** to select "Colour sys.", and then press **ENTER**.

- Receivable colour systems are listed.

Colour system menu

MENU [Setup --- Programme Setup]		
Search		
Fine	[179.25]	
Colour sys.	[Auto]	Auto
Sound sys.	[B/G]	PAL
Label	[SAT.1]	SECAM
Skip	[Off]	NTSC 3.58
Lock	[Off]	NTSC 4.43
		PAL-60

3

Press **▲/▼** to select the optimum colour system, and then press **ENTER**.

Sound system (Broadcasting system)

1

Press **▲/▼/◀/▶** to select the channel you want to edit, and then press **ENTER**.

- The selected channel information displays.

2

Press **▲/▼** to select "Sound sys.", and then press **ENTER**.

- Receivable sound systems (Broadcasting systems) are listed.

Sound system menu

Search		
Fine	[179.25]	
Colour sys.	[Auto]	B/G
Sound sys.	[B/G]	D/K
Label	[SAT.1]	I
Skip	[Off]	M
Lock	[Off]	

3

Press **▲/▼** to select the optimum sound system, and then press **ENTER**.

Labelling channels

When a TV channel sends its Network Name, the auto installation detects the information and assigns a name to it. However, you can change individual channel names.

1

Press **▲/▼/◀/▶** to select the channel you want to edit, and then press **ENTER**.

- The selected channel information displays.

2

Press **▲/▼** to select "Label", and then press **ENTER**.

- Alphabets and numbers are listed.

Labelling menu

Search		
Fine	[179.25]	
Colour sys.	[Auto]	A B C D E F G H I J CLEAR
Sound sys.	[B/G]	K L M N O P Q R S T BACK
Label	[SAT.1]	U V W X Y Z + - . _
Skip	[Off]	0 1 2 3 4 5 6 7 8 9 END
Lock	[Off]	

3

Press **▲/▼/◀/▶** to select each character of the new name for the channel, and then press **ENTER**.

4

Repeat until the name is fully spelt out.

- The name can be 5 characters or less.
- When you want to set a channel name of less than 5 characters, select "END", then press **ENTER** to exit from the labelling menu.

Basic adjustment settings

Manual setting for each channel (continued)

Skipping channels

Channels with “Skip” set to “On” are passed over when using **CH** Δ/∇ even if selected while watching the image from the TV.

- 1 Press $\Delta/\nabla/\leftarrow/\rightarrow$ to select the channel you want to edit, and then press **ENTER**.
 - The selected channel information will be displayed.

- 2 Press Δ/∇ to select “Skip”, and then press **ENTER**.
 - Skip menu displays.

Skip menu

MENU [Setup --- Programme Setup]	
Search	
Fine [179.25]	Off
Colour sys. [Auto]	
Sound sys. [B/G]	On
Label [SAT.1]	
Skip [Off]	
Lock [Off]	

- 3 Press Δ/∇ to set “Skip” to “On”, and then press **ENTER**.

Setting the child lock

You can block the viewing of any channel.

- 1 Press $\Delta/\nabla/\leftarrow/\rightarrow$ to select the channel you want to edit, and then press **ENTER**.
 - The selected channel information will be displayed.

- 2 Press Δ/∇ to select “Lock”, and then press **ENTER**.
 - Child lock menu will be displayed.

Lock menu

Search	
Fine [179.25]	Off
Colour sys. [Auto]	
Sound sys. [B/G]	On
Label [SAT.1]	
Skip [Off]	
Lock [Off]	

- 3 Press Δ/∇ to set “Lock” to “On”, and then press **ENTER**.

NOTE

- See page 31 for setting a password.
- If “Lock” is set to “On” for a channel, “Child lock has been activated.” is displayed when you select the channel, and the image and sound of the channel is blocked.
- When pressing **ENTER** while “Child lock has been activated.” is displayed, password input menu will be displayed. Inputting the correct password lifts the child lock temporarily until the power is turned off.

Sort

Channel positions can be sorted freely.

- 1 Press **MENU** and the MENU screen displays.

- 2 Press \leftarrow/\rightarrow to select “Setup”.

- 3 Press Δ/∇ to select “Programme Setup”, and then press **ENTER**.
 - If you already set the password, enter it here.
 - See page 31 for setting a password.

- 4 Press Δ/∇ to select “Sort”, and then press **ENTER**.

- 5 Press \leftarrow/\rightarrow to select “Yes”, and then press **ENTER**.

- 6 Press $\Delta/\nabla/\leftarrow/\rightarrow$ to select the channel you want to move, and then press **ENTER**.

- 7 Move it to the desired position by pressing $\Delta/\nabla/\leftarrow/\rightarrow$, and then press **ENTER**.

- 8 Repeat the steps 6 and 7 until all desired channels are sorted.

Sort menus

01 SAT.1 ↔				
01 SAT.1	02 KABEL	03	04	05
06				
Next				



01 SAT.1 ↔ 02 KABEL				
01 SAT.1	02 KABEL			
Next				



01 KABEL ↔				
01 KABEL	02 SAT.1			
Next				

Basic adjustment settings

Erase Programme

The individual programme can be erased.

1 Press **MENU** and the MENU screen displays.

2 Press **◀/▶** to select “Setup”.

3 Press **▲/▼** to select “Programme Setup”, and then press **ENTER**.
If you already set the password, enter it here.
• See page 31 for setting a password.

4 Press **▲/▼** to select “Erase Programme”, and then press **ENTER**.

5 Press **◀/▶** to select “Yes”, and then press **ENTER**.

6 Press **▲/▼/◀/▶** to select the channel you want to erase, and then press **ENTER**.
• A message screen pops up.

7 Press **◀/▶** to select “Yes”, and then press **ENTER** to erase the selected programme. All the subsequent programmes move up.

8 Repeat the steps 6 and 7 until all desired channels are erased.

Erase programme menus

01 SAT.1				
01 SAT.1	02 Pro7	03 KABEL	04	05
06	07	08	09	10
11	12	13	14	15
16	17	18	19	20
Next				



02 Pro7				
01 SAT.1	02 Pro7	03 KABEL	04	05
06	07	08	09	10
11	12	13	14	15
16	17	18	19	20
Next				



02 KABEL				
01 SAT.1	02 KABEL	03	04	05
06	07	08	09	10
11	12	13	14	15
16	17	18	19	20
Next				

Basic adjustment settings


AV MODE selection

AV MODE gives you seven viewing options to choose from to best match the system environment, which can vary due to factors like room-brightness, type of programme watched or the type of image input from external equipment.


Using AV MODE on the remote control unit

- 1 Press **AV MODE**.
 - Present AV MODE displays.
- 2 Press **AV MODE** again before the mode displayed on the screen disappears.
 - The mode changes as shown below.

When the input source is TV, INPUT1, 2 or 3 terminals (Example)



When the input source is INPUT4, 5 or 6 terminals (Example)



Selected item	Description
STANDARD	For a highly defined image in a normally bright room
MOVIE	For a movie
GAME	Lowers image brightness for easier viewing.
PC	For PC. (Available only when inputting an HDMI or DVI signal.)
USER	Allows the user to customise settings as desired. You can set the mode for each input source.
DYNAMIC (Fixed)	Changes the image and sound settings to the factory preset values. No adjustments are allowed.
DYNAMIC	For a clear-cut image emphasising high contrast for sports viewing


NOTE

- You can select a different AV MODE item for each input mode. (For example, select STANDARD for TV input and DYNAMIC for VIDEO input.)

OPC (Optical Picture Control) setting

You can set the TV to automatically adjust the screen to suitable backlight brightness according to the lighting conditions.

Using OPC on the remote control unit



Press **OPC** to switch the OPC function on and off.

Using OPC on the menu screen

- 1 Press **MENU** and the MENU screen displays.
- 2 Press **◀/▶** to select “Picture”.
- 3 Press **▲/▼** to select “OPC”.
- 4 Press **◀/▶** to select the desired item, and then press **ENTER**.

Selected item	Description
Off	The brightness is fixed at the value set in “Backlight” (See page 26).
On	Automatically adjusts
On: Display	Displays the OPC effect on the screen while adjusting the brightness of the screen.


NOTE

- Make sure no object obstructs the OPC sensor, which could affect its ability to sense surrounding light.

Basic adjustment settings

Picture adjustments

You can adjust the picture to your preference.
Follow the steps to adjust the picture.



- 1 Press **MENU** and the MENU screen displays.
- 2 Press **◀▶** to select “Picture”.
- 3 Press **▲▼** to select a specific adjustment item.
- 4 Press **◀▶** to adjust the item to your desired position.

NOTE

- For resetting all adjustment items to factory preset values, press **▲▼** to select “Reset”, press **ENTER**, press **◀▶** to select “Yes”, and then press **ENTER**.

Adjustments items

MENU [Picture]

Picture Audio

STANDARD

OPC ☒ Off ☐ On ☐ On: Display

Backlight [+14] -16 +16

Contrast [+30] 0 +40

Brightness [0] -30 +30

Colour [0] -30 +30

Tint [0] -30 +30

Sharpness [0] -10 +10

Advanced

Reset

Selected item	◀ button	▶ button
Backlight	The screen dims	The screen brightens
Contrast	For less contrast	For more contrast
Brightness	For less brightness	For more brightness
Colour	For less colour intensity	For more colour intensity
Tint	Skin tones become purplish	Skin tones become greenish
Sharpness	For less sharpness	For more sharpness

NOTE

- Select “Advanced” and then press **ENTER** to set “Colour Temp.”, “Black”, “Quick Shoot”, “3D-Y/C”, “Monochrome”, “Film Mode” or “Range of OPC”. See pages 27 and 28.

Basic adjustment settings

Advanced

Advanced setting enables you to set the picture adjustment in more detail. There are seven options you can choose from.

Colour temperature

Adjusts the colour temperature to give the best white image.

1 Press **MENU** and the MENU screen displays.

2 Press **◀/▶** to select “Picture”.

3 Press **▲/▼** to select “Advanced”, and then press **ENTER**.

4 Press **▲/▼** to select “Colour Temp.”, and then press **ENTER**.

5 Press **▲/▼** to select the desired level, and then press **ENTER**.

Selected item	Description
High	White with bluish tone ↑↓
Mid-High	
Middle	
Mid-Low	
Low	White with reddish tone

Black

For easier viewing, change the viewing depth by selecting a level for automatically adjusting the dark portion of an image.

1 Repeat steps 1 to 3 in **Colour temperature**.

2 Press **▲/▼** to select “Black”, and then press **ENTER**.

3 Press **◀/▶** to select “On”, and then press **ENTER**.

Colour Temp.	
Black	
Quick Shoot	
3D - Y/C	
Monochrome	
Film Mode	
Range of OPC	

Selected item	Description
On	For high detail in black portions
Off	No adjustment

Quick Shoot

Use Quick Shoot to view fast-action video more clearly.

1 Repeat steps 1 to 3 in **Colour temperature**.

2 Press **▲/▼** to select “Quick Shoot”, and then press **ENTER**.

3 Press **◀/▶** to select “Advanced”, and then press **ENTER**.

Selected item	Description
Advanced	For obtaining a clear image
Standard	Normal image

NOTE

- Quick Shoot may cause image noise. If this occurs, set the function to “Standard”.
- Quick Shoot is not selectable on 50 Hz input signals, e.g. PAL 50 Hz.

3D-Y/C

Provides high quality images with minimal dot crawl and cross colour noise.

1 Repeat steps 1 to 3 in **Colour temperature**.

2 Press **▲/▼** to select “3D-Y/C”, and then press **ENTER**.

Colour Temp.	
Black	
Quick Shoot	
3D - Y/C	
Monochrome	
Film Mode	
Range of OPC	

3 Press **▲/▼** to select the desired level, and then press **ENTER**.

Selected item	Description
Standard	Normal adjustment
Fast	For movie image
Slow	For still image

NOTE

- 3D-Y/C is not selectable depending on the input signal type.
- 3D-Y/C may not operate depending on the input signal type or noisy input signal.

Basic adjustment settings

Monochrome

For viewing a video in monochrome.

- 1 Press **MENU** and the MENU screen displays.
- 2 Press ◀▶ to select "Picture".
- 3 Press ▲▼ to select "Advanced", and then press **ENTER**.
- 4 Press ▲▼ to select "Monochrome", and then press **ENTER**.
- 5 Press ◀▶ to select "On", and then press **ENTER**.

Film Mode

Automatically detects a film-based source (originally encoded at 24/25 frames/second, depending on the vertical frequency), analyses it then recreates each still film frame for high-definition picture quality.

- 1 Repeat steps 1 to 3 in **Monochrome**.
- 2 Press ▲▼ to select "Film Mode", and then press **ENTER**.
- 3 Press ◀▶ to select "On", and then press **ENTER**.

NOTE

- Film Mode is not selectable depending on the input signal type.

Range of OPC

The brightness level range of the OPC sensor's automatic adjustments can be set according to your preferences. The adjustment range of the OPC sensor can be set to a maximum of +16 and a minimum of -16.

- 1 Repeat steps 1 to 3 in **Monochrome**.
- 2 Press ▲▼ to select "Range of OPC", and then press **ENTER**.
- 3 Press ▲▼ to select "Max." or "Min.", and then adjust the item to the desired position.

Selected item	Description
Max.	-15 through +16
Min.	-16 through +15

NOTE

- The range of OPC can only be adjusted when the OPC is set to On.
- The maximum setting cannot be set to a smaller number than the minimum setting.
- The minimum setting cannot be set to a bigger number than the maximum setting.
- The maximum and minimum settings cannot be set to the same number.
- Depending on the brightness of the surrounding light, the OPC sensor might not operate if the adjustment range is small.

Basic adjustment settings

Audio adjustment

You can adjust the sound quality to your preference with the following settings.

- 1

Press **MENU** and the MENU screen displays.
- 2

Press ◀▶ to select "Audio".

MENU [Audio]

Audio

Power Control

STANDARD

Treble [0] -15 ▶◀ +15

Bass [0] -15 ▶◀ +15

Balance [0] L ▶◀ R

Surround [Off]

Reset
- 3

Press ▲▼ to select a specific adjustment item.
- 4

Press ◀▶ to adjust the item to your desired position.

Selected item	◀button	▶button
Treble	For weaker treble	For stronger treble
Bass	For weaker bass	For stronger bass
Balance	Decrease audio from the right speaker	Decrease audio from the left speaker


NOTE

- For resetting all adjustment items to factory preset values, press ▲/▼ to select "Reset", press **ENTER**, press ◀▶ to select "Yes", and then press **ENTER**.
- Audio menu items are greyed out when headphones are in use.

Surround

When you set to "On", you can enjoy surround sound, the same as if you were in a movie theatre.

Using SURROUND on the remote control unit



Press **SURROUND** to switch the Surround function on and off.

Selected item	Description
On	Makes it possible to enjoy natural, realistic surround sound.
Off	Outputs the normal sound.

Using Surround on the menu screen

You can produce Surround effects from the "Audio" setting.

- 1

Press **MENU** and the MENU screen displays.
- 2

Press ◀▶ to select "Audio".
- 3

Press ▲/▼ to select "Surround", and then press **ENTER**.

MENU [Audio ... Surround]

Audio

Power Control

STANDARD

Treble [0] -15 ▶◀ +15

Bass [0] -15 ▶◀ +15

Balance [0] L ▶◀ R

Surround [Off]

Reset
- 4

Press ◀▶ to select "On", and then press **ENTER**.

NOTE

- Audio menu items are greyed out when headphones are in use.

Basic adjustment settings

Power Control

Power control setting allows you to save energy.

No Signal Off

When set to "Enable", the power will automatically shut down if no signal inputs for 15 minutes.

1

Press **MENU** and the MENU screen displays.

2

Press ◀/▶ to select "Power Control".
• Power control menu displays.

3

Press ▲/▼ to select "No Signal Off", and then press **ENTER**.

4

Press ◀/▶ to select "Enable", and then press **ENTER**.
• Five minutes before the power shuts down, remaining time displays every minute.

NOTE

- "Disable" is factory preset value.
- When a TV programme finishes, this function may not operate.

No Operation Off

When set to "Enable", the power will automatically shut down if there is no operation for 3 hours.

1

Press **MENU** and the MENU screen displays.

2

Press ◀/▶ to select "Power Control".
• Power control menu displays.

3

Press ▲/▼ to select "No Operation Off", and then press **ENTER**.

4

Press ◀/▶ to select "Enable", and then press **ENTER**.
• Five minutes before the power shuts down, remaining time displays every minute.


NOTE

- "Disable" is factory preset value.

Useful adjustment settings

Password setting for child lock (for TV input mode)

Allows you to use a password to protect certain settings from being accidentally changed.



Setting a password

Register a 4-digit password number to use the Child Lock function.

1 Press **MENU** and the MENU screen displays.

2 Press **◀▶** to select “Setup”.

3 Press **▲▼** to select “Child Lock”, and then press **ENTER**.

4 If you already set the password, enter it here.

5 Press **▲▼** to select “Change password”, and then press **ENTER**.

Change password	
Reset	
New Password	- - - -
Reconfirm	- - - -

6 Enter the 4-digit number as a password using **0 – 9**.

Change password	
Reset	
New Password	█ - - -
Reconfirm	- - - -

7 Enter the same 4-digit number as in step 6 to confirm.

- “The new password was registered.” displays.

NOTE

- To view a locked channel (Lock setting in Programme Setup “Manual Adjust” is set to “On”), you must enter a password. (See page 23.) When you select a locked channel, a password prompt message pops up. Press **ENTER** to display the password input window.

Resetting the password

Allows you to reset your password.

1 Press **MENU** and the MENU screen displays.

2 Press **◀▶** to select “Setup”.

3 Press **▲▼** to select “Child Lock”, and then press **ENTER**.

4 Enter the password.

5 Press **▲▼** to select “Reset”, and then press **ENTER**.

6 Press **◀▶** to select “Yes”, and then press **ENTER**.

Change password	
Reset	
<div>Yes</div> <div>No</div>	

NOTE


- As a precautionary measure, make a note of your password and keep it in a familiar place. If you lose or forget your password, initialise the TV to return all settings except for the TV channel settings to factory preset values. (See page 52.)
- This function is only available for TV input mode.
- To relock a channel which has been temporarily unlocked by inputting the correct password, turn power off and then on again.

Speaker Setup

Connecting external speakers

- 1 Press **POWER** on the top TV panel to turn it off.
- 2 Connect external speakers to the TV.

Rear view



Connecting speaker cables

- ① Push up the tab.
- ② Insert the end of the cable into the hole while pressing up on the tab.
- ③ Release the tab.

CAUTION

- Make sure external speakers have 4 ohm and 15 watt specifications.
- Speaker terminals and speaker cables have plus and minus polarities. Make sure that each polarity of terminals and cables is connected with the same polarity when connecting external speakers.
- Insert the speaker cable's lead wire carefully so that it goes straight to the hole of the speaker terminal. The speaker cable needs to be firmly inserted until the speaker cable's lead wire reaches the metal part of the speaker terminal.

External Audio Bypass

External Audio Bypass automatically optimises the audio quality to suit internal (supplied) speakers.

- 1 Press **MENU** and the MENU screen displays.
- 2 Press **◀/▶** to select "Setup".
- 3 Press **▲/▼** to select "Speaker Setup", and then press **ENTER**.
- 4 Press **▲/▼** to select "External Audio Bypass", and then press **ENTER**.
- 5 Press **◀/▶** to select "Yes" or "No", and then press **ENTER**.

Selected item	Description
Yes	When you are using your own speakers, output the original sound.
No	Sets the optimum audio for the internal (supplied) speakers.

Useful adjustment settings

Input Skip


This setting allows you to skip the HDMI or DVI input on the Input Selection operation.

1 Press **MENU** and the MENU screen displays.

2 Press **◀/▶** to select "Setup".

3 Press **▲/▼** to select "Input Skip", and then press **ENTER**.

4 Press **▲/▼** to select the Input (INPUT4, INPUT5 or INPUT6) you wish to skip, and then press **ENTER**.



5 Press **◀/▶** to select "Yes", and then press **ENTER**.

6 Press **MENU** to exit.

Input Signal (PC input mode only)

- Some input signals may have to be registered manually to display properly.
- The pairs of input signals (resolutions) in the list below are not distinguishable when received. In such case, you have to set the correct signal manually. After setting once, it will display when the same signal (resolution) is input again.

1024 × 768	1360 × 768
------------	------------

NOTE


- You can only select the "Input Signal" on the Setup menu when receiving one of the 2 input signals listed above.

1 Press **MENU** and the MENU screen displays.

2 Press **◀/▶** to select "Setup".

3 Press **▲/▼** to select "Input Signal" and then press **ENTER**.

4 Press **▲/▼** to select the desired input signal on the display.





(Example)

Useful adjustment settings

Auto Sync. adjustment (PC input mode only)

For automatically adjusting the PC image.

- 1 Press **MENU** and the MENU screen displays.
- 2 Press ◀/▶ to select “Setup”.
- 3 Press ▲/▼ to select “Auto Sync.”, and then press **ENTER**.
- 4 Press ◀/▶ to select “Yes”, and then press **ENTER**.
 - Auto Sync. starts and “Adjusting the image” displays.



- 5 Press **MENU** to exit.


NOTE

- When Auto Sync. is successful, “Auto Sync completed successfully” displays. If not, Auto Sync. failed.
- Auto Sync. may fail even if “Auto Sync completed successfully” displays.
- Auto Sync. may fail if the computer image has low resolution, has unclear (black) edges, or is moved while executing Auto Sync.
- Be sure to connect the PC to the TV and switch it on before starting Auto Sync.
- Auto Sync. can be executed only when inputting analogue signals.

Fine Sync. adjustment (PC input mode only)

Ordinarily you can easily adjust the picture as necessary to change image position using Auto Sync. In some cases, however, manual adjustment is needed to optimize the image.

- 1 Press **MENU** and the MENU screen displays.
- 2 Press ◀/▶ to select “Setup”.
- 3 Press ▲/▼ to select “Fine Sync.”, and then press **ENTER**.
- 4 Press ▲/▼ to select the specific adjustment item.



Selected item	Description
H-Pos.	Centres the image by moving it to the left or right.
V-Pos.	Centres the image by moving it up or down.
Clock	Adjusts when the image flickers with vertical stripes.
Phase	Adjusts when characters have low contrast or when the image flickers.

- 5 Press ◀/▶ to adjust the item to your desired position.
- 6 Press **MENU** to exit.


NOTE

- For resetting all adjustment items to the factory preset values, press ▲/▼ to select “Reset”, and then press **ENTER**.
- “Clock” and “Phase” in the “Fine Sync” menu can be adjusted only when inputting analogue signals.


Useful adjustment settings

Input Label

You can assign each input source a label you like.




- 1 Press **TV/VIDEO** to select the desired input source.
- 2 Press **MENU** and the MENU screen displays.
- 3 Press **◀/▶** to select “Setup”.
- 4 Press **▲/▼** to select “Input Label”, and then press **ENTER**.
- 5 Press **▲/▼/◀/▶** to select each character of the new name for the input source, and then press **ENTER**.



(Example)

- 6 Repeat until the name is fully spelt out.
 - The name can be 6 characters or less.
 - When you want to set an input source name of less than 6 characters, select “END”, then press **ENTER** to exit from the labelling menu.



(Example)


NOTE

- You cannot change labels if the INPUT SOURCE is TV.

Image position

For adjusting a picture's horizontal and vertical position.

- 1 Press **MENU** and the MENU screen displays.
- 2 Press **◀/▶** to select “Setup”.
- 3 Press **▲/▼** to select “Position”, and then press **ENTER**.
- 4 Press **▲/▼** to select “H-Pos.” or “V-Pos.”.
- 5 Press **◀/▶** to adjust the item to your desired position.



Selected item	Description
H-Pos.	Centres the image by moving it to the left or right.
V-Pos.	Centres the image by moving it up or down.

NOTE

- For resetting all adjustment items to the factory preset values, press **▲/▼** to select “Reset”, and then press **ENTER**.
- **Adjustments are stored separately according to input source.**

Useful adjustment settings

Wide Screen Signalling (WSS)

WSS allows a television to switch automatically among the different screen formats.

- 1 Press **MENU** and the MENU screen displays.
- 2 Press ◀▶ to select “Setup”.
- 3 Press ▲▼ to select “WSS”, and then press **ENTER**.
- 4 Press ◀▶ to select “On” or “Off”, and then press **ENTER**.

NOTE

- Try to set WIDE mode if an image does not switch to the correct screen format. When the broadcast signal contains no WSS information, the function will not work even if enabled.

Picture aspect ratio

The WSS signal has 4:3 auto-switching that allows you to select between Panorama and Normal.

- 1 Press **MENU** and the MENU screen displays.
- 2 Press ◀▶ to select “Setup”.
- 3 Press ▲▼ to select “4:3 Mode”, and then press **ENTER**.
- 4 Press ◀▶ to select “Panorama” or “Normal”, and then press **ENTER**.

WSS signal 4:3 screen

4:3 mode “Panorama”



4:3 mode “Normal”



Selected item	Description
Panorama	Wide image without side bars
Normal	Normal range keeping 4:3 or 16:9 aspect ratio

Useful adjustment settings

Standby Mode

Standby Mode may be set to either start the TV quickly from standby or conserve energy while on standby.

- 1 Press **MENU** and the MENU screen displays.
- 2 Press ◀/▶ to select "Setup".
- 3 Press ▲/▼ to select "Standby Mode", and then press **ENTER**.
- 4 Press ▲/▼ to select "Mode1" or "Mode2", and then press **ENTER**.


Selected item	Description
Mode1	Starting the TV is quick from standby.
Mode2	Power consumption is small during standby.

- 5 Press **MENU** to exit.

Reset

If complex adjustments are made and the settings cannot be restored to normal, you can reset the settings to the factory preset values.




- 1 Press **MENU** and the MENU screen displays.
- 2 Press ◀/▶ to select "Setup".
- 3 Press ▲/▼ to select "Reset", and then press **ENTER**.
 - "Return to factory pre-settings" displays on the screen.
- 4 Press ◀/▶ to select "Yes", and then press **ENTER**.
 - "Now, TV will restart automatically. OK?" displays on the screen.
- 5 Press ◀/▶ to select "Yes", and then press **ENTER**.
 - "Now initialising..." displays on the screen and blinks.
 - After the reset has completed, the power shuts off and then comes back on. The screen will have returned to its original settings.




NOTE

- The AV MODE will be set to "DYNAMIC".
- The Programme Setup settings will not be changed.
- The Language settings will not be changed.

Useful adjustment settings



4:3 Mode set to "Panorama"



4:3 Mode set to "Normal"

WIDE mode (for TV/AV input mode)

Manual Selection

- 1 Press **WIDE**.
 - The WIDE MODE menu displays.
 - The menu lists the wide mode options selectable for the type of video signal currently received.
- 2 Press **WIDE** or **▲/▼** while the WIDE MODE menu displays on the screen.
 - As you toggle down the options, each is immediately reflected on the TV.

Auto Selection

If you set "WSS" and "4:3 Mode" in the Setup menu on page 36, the optimum WIDE mode is automatically chosen for every broadcast containing the WSS information.

"WSS" menu

To enable Auto Selection, set "WSS" in the Setup menu to "On". (See page 36.)


"4:3 Mode" menu

To set the type of the wide screen, select "Panorama" or "Normal" in the 4:3 Mode menu. (See page 36.)

NOTE

- If the broadcast signal contains no WSS information, Auto Selection will not function even when the WSS option is enabled.

Selected item	Description
Normal	For 4:3 "standard" pictures. A side bar appears on each side.
Zoom 14:9	For 14:9 letterbox pictures. A thin side bar appears on each side, and you may also see bars on the top and bottom with some programmes.
Panorama	In this mode the picture is progressively stretched toward each side of the screen.
Full	For 16:9 squeeze pictures.
Cinema 16:9	For 16:9 letterbox pictures. Bars may appear on the top and bottom with some programmes.
Cinema 14:9	For 14:9 letterbox pictures. Bars may appear on the top and bottom with some programmes.
Dot by Dot	Displays an image with the same number of pixels on the screen (only when receiving 1080i/1080p signal).



NOTE


- Screen sizes may not toggle in the order illustrated on the left, depending on the input signal.

WIDE mode (for PC input mode)

You can select the screen size.


NOTE

- Connect the PC before making adjustments.
- Selectable screen size may vary with input signal type.



1

- Press **WIDE**.
- The WIDE MODE menu displays.



(Example)

2

- Press **WIDE** or **▲/▼** to select a desired item on the menu.

EXAMPLE

Screen size images.

Input Signal	Normal	Cinema	Full	Dot by Dot
 1024 × 768	 Keeps the original aspect ratio in a full screen display.	 For viewing wide-screen programs. The top and bottom of the image is slightly cropped.	 An image fully fills the screen.	 Detects the resolution of the signal and displays an image with the same number of pixels on the screen.
Input Signal			Full	Dot by Dot
 1360 × 768			 An image fully fills the screen.	 Detects the resolution of the signal and displays an image with the same number of pixels on the screen.

Useful adjustment settings

Audio Only

When listening to music from a music programme, you can set the display off and enjoy audio only.

- 1 Press **MENU** and the MENU screen displays.
- 2 Press **◀/▶** to select “Option”.
- 3 Press **▲/▼** to select “Audio Only”, and then press **ENTER**.
- 4 Press **◀/▶** to select “On”, and then press **ENTER**.

Selected item	Description
On	Audio is output without screen image.
Off	Both screen images and audio are output.

NOTE

- When you make operations that change the picture on the TV such as by changing the input source, the Audio Only function is set to “Off”.

DNR (Digital Noise Reduction)

Produces a clearer video image.


- 1 Press **MENU** and the MENU screen displays.
- 2 Press **◀/▶** to select “Option”.
- 3 Press **▲/▼** to select “DNR”, and then press **ENTER**.
- 4 Press **▲/▼** to select the desired level, and then press **ENTER**.



HDMI Setup

HDMI (High-Definition Multimedia Interface) terminal selection.

- 1 To watch an HDMI equipment image, select “INPUT4” or “INPUT5” using **TV/VIDEO** on the remote control unit or on the TV.
- 2 Press **MENU** and the MENU screen displays.
- 3 Press **◀/▶** to select “Option”.
- 4 Press **▲/▼** to select “HDMI Setup”, and then press **ENTER**.
 - The HDMI Setup can be selected only when “INPUT4” or “INPUT5” is selected.
- 5 Press **▲/▼** to select the desired item, and then press **ENTER**.



HDMI Setup items	Selectable items	Description
Signal Type	RGB/YCbCr 4:4:4/ YCbCr 4:2:2	Select the video signal type from the HDMI terminal.
Auto View	Enable/Disable	Set whether or not to use WIDE MODE based on signal recognition, including an HDMI signal.
Audio Select	Digital/Analogue	Select “Digital” for audio signal via the HDMI terminal. Select “Analogue” for audio signal via the AUDIO jack.

- 6 Press **▲/▼/◀/▶** to select the desired setting, and then press **ENTER**.

NOTE

- Refer to your external equipment operation manual for the signal type.
- Item under “Signal Type” can be selected when the equipment is connected with a DVI-HDMI conversion cable.
- When the equipment is connected with an HDMI cable, items are automatically set and cannot be selected.
- “Audio Select” is only available for INPUT5.

Useful adjustment settings

Language setting for on-screen display

You can also select a language from setup menu. Select from among 3 languages: English, Chinese and Arabic.

1 Press **MENU** and the MENU screen displays.

2 Press ◀/▶ to select "Setup".

3 Press ▲/▼ to select "Language", and then press **ENTER**.

4 Press ▲/▼ to select the desired language listed on the screen, and then press **ENTER**.

Identification

You can check the current version of the software on the screen.

Colour system setting


You can change the colour system to one that is compatible with the image on the screen.

1 Press **MENU** and the MENU screen displays.

2 Press ◀/▶ to select "Option".

3 Press ▲/▼ to select "Colour System", and then press **ENTER**.

4 Press ▲/▼ to select a compatible video signal system of your equipment, and then press **ENTER**.




NOTE

- Factory preset value is "Auto".
- If "Auto" is selected, colour system for each channel is automatically set. If an image does not display clearly, select another colour system (e.g. PAL, NTSC 4.43).

Using external equipment

Displaying an external equipment image

Explanation here is for the setting when connecting DVD to INPUT1 terminal.




NOTE

- Each time **TV/VIDEO** is pressed, the input source toggles.
- If the image does not come in clearly, you may need to change the input signal type setting on the "Input Select" menu.
- Refer to your external equipment operation manual for the signal type.

Displaying a DVD image (Example)

1


To watch a DVD image, select "INPUT1" using **TV/VIDEO** on the remote control unit or **TV/VIDEO** on the TV.



2

Select the desired signal type on "Input Select" in the "Option" menu.

For INPUT1 signal



The setting is stored and can be selected.

Input Select

Selecting input source

Can use for selecting the input source.

Using TV/VIDEO on the remote control unit or on the TV

TV/VIDEO allows you to choose from the available input sources.

1

Press **TV/VIDEO** on the remote control unit or on the TV.


2

Press **TV/VIDEO** on the remote control unit or on the TV to select the input source.

- The image and sound from the selected source are output on the TV.
- You can also select the input source by pressing **▲/▼**.

Using INPUT4 or 5 (HDMI) on the remote control unit

INPUT4 or **5 (HDMI)** allows you to directly select the HDMI input source.



Press **INPUT4** or **5 (HDMI)** on the remote control.

- The image and sound from the HDMI input source are output on the TV.

Selecting input signal type

For setting the signal type of external equipment.

1

Press **MENU** and the MENU screen displays.

2

Press **◀/▶** to select "Option".

3

Press **▲/▼** to select "Input Select", and then press **ENTER**.

4

Press **▲/▼** to select a signal type you want to set, and then press **ENTER**.

Input source	Selectable item
INPUT 1/INPUT 2	Auto, COMPONENT, VIDEO
INPUT 3	Auto, S-VIDEO, VIDEO
INPUT 6	Auto, DIGITAL, ANALOGUE

NOTE

- If no (colour) image displays, try to change the other signal type.
- Check the operation manual of the external equipment for the signal type.
- When the signal type is set to "Auto", the input terminal where cable is connected is automatically selected.
- When the signal type is set to "Auto" and multiple video signal cables are connected, the signal type is selected in the following prioritised order:
INPUT 1/INPUT 2: COMPONENT → VIDEO
INPUT 3: S-VIDEO → VIDEO
- When the signal type for "INPUT6" is set to "DIGITAL" or "ANALOGUE", a "PC" or "AV" signal is automatically detected.


Useful features


Teletext function

What is Teletext?




Teletext broadcasts pages of information and entertainment to specially equipped television sets. Your TV receives Teletext signals broadcast by a TV network, and decodes them into graphical format for viewing. News, weather reports, sports information, stock exchange prices and programme previews are among the many services available.


Teletext mode

Teletext is turned on/off with  on the remote control unit. You can operate your TV in Teletext mode directly by inputting commands with the remote control unit.





Turning on and off Teletext

- 1** Select a TV channel or external input source providing the Teletext programme.
- 2** Press  to display the Teletext.
- 3** Press  again to display the Teletext on the right screen and normal image on the left screen.
 - Each time you press , the screen switches as shown upper right.
 - If you select a programme with no Teletext signal, "No Teletext available." is displayed.
 - The same message displays during other modes if no Teletext signal is available.




When viewing the Teletext information

- Press **CH**  to increase the page number.
- Press **CH**  to decrease the page number.

Button functions

Colour (Red/Green/Yellow/Blue):

You can select a group or block of pages displayed in the coloured brackets at the bottom of the screen by pressing the corresponding **Colour (Red/Green/Yellow/Blue)** on the remote control unit.




0 – 9:


Directly select any page from 100 to 899 by using **0 – 9**.


(Top/Bottom/Full):

Each time you press , the TELETEXT image switches as shown below.




(Reveal hidden for TELETEXT):

To reveal hidden information such as an answer to a quiz, press .

- Press  again to hide the information.

(Hold):


To stop updating Teletext pages automatically, press .

- Press  again to release the hold mode.

Useful features

Displaying Subtitle

You can display several subtitles as they are transmitted.



- 1 Press to display the subtitle.
 - Subtitle is updated by information sent by the broadcasting station.
 - To stop updating subtitle automatically, press .

- 2 Press to exit the subtitle screen.

NOTE

- Subtitle will not be displayed when the service does not contain the subtitle information.

Time display

You can display the time information included in the Teletext broadcast.

- 1 Select a TV channel providing Teletext information.
(The time information is automatically captured.)

- 2 Press **DISPLAY**. The channel display will appear on the display.

- 3 Press **DISPLAY** again within the three-second interval the channel display is on the screen.
Time information will display on the lower left of the screen for about three seconds.


- 4 Even when you change the TV channel, you can display the time information with steps 2 to 3 above.

NOTE

- The time display cannot be stored once the power is turned off. When you turn on the power, perform steps 1 to 4 again.
- If acquired successfully the time information will appear in the upper-right corner of the screen by pressing **MENU**.

Displaying Subpages


You can display several subpages as they are transmitted.



- 1 Press to display Teletext.

- 2 Press to display the subpage as shown below.

Subpage screen



- 3 Select the desired subpage by using **CH** **CH** , **Red** or **Green**.

- **0 – 9** directly selects the desired subpage.

- 4 Press to exit the subpage screen.

Useful features

Teletext language setting

If Teletext information does not display correctly, perform the setting procedure below. Select from among 4 kinds of language tables: West Europe, East Europe, Greek/Turkish, Cyrillic. Each table is compatible with the Teletext languages listed below.


1 Press **MENU** and the MENU screen displays.

2 Press ◀▶ to select "Setup".

3 Press ▲/▼ to select "Text Language", and then press **ENTER**.

4 Press ▲/▼ to select receivable teletext broadcasting language in your country.

MENU [Setup ... Text Language]




- West Europe - English, French, Scandinavian, Czech, German, Spanish, Italian
- East Europe - Polish, French, Scandinavian, Czech, German, Slovenian/Croatian, Italian, Rumanian
- Greek/Turkish - English, French, Scandinavian, Turkish, German, Spanish, Italian, Greek
- Cyrillic - English, Russian, Estonian, Czech, German, Spanish, Ukrainian, Lettish

NOTE

- Teletext can display only when it is sent by a network. Not used to convert between languages.

Freezing images

Allows you to capture and freeze one frame from a moving image that you are watching.



1 Press **FREEZE**.

- Captures one frame from a moving image.

2 Press **FREEZE** again to cancel the function.

NOTE

- This function does not work in INPUT 6.
- When this function is not available, "No still image display available." will display.
- The still image automatically goes out after 30 minutes.

Appendix

Troubleshooting

Problem	Possible Solution
<ul style="list-style-type: none"> No power. 	<ul style="list-style-type: none"> Check if you pressed POWER on the remote control unit. (See page 15.) If the indicator on the TV lights up red, press POWER. Is the AC cord disconnected? (See page 6.) Has the power been turned on? (See page 15.)
<ul style="list-style-type: none"> Unit cannot be operated. 	<ul style="list-style-type: none"> External influences such as lightning, static electricity, etc., may cause improper operation. In this case, operate the unit after first turning the power off the TV or unplugging the AC cord and re-plugging it in after 1 or 2 minutes.
<ul style="list-style-type: none"> Remote control unit does not operate. 	<ul style="list-style-type: none"> Are batteries inserted with polarity (+ , -) aligned? (See page 5.) Are batteries worn out? (Replace with new batteries.) Are you using it under strong or fluorescent lighting? Is a fluorescent light illuminated to remote control sensor?
<ul style="list-style-type: none"> Picture is cut off. 	<ul style="list-style-type: none"> Is the image position correct? (See page 35.) Are screen mode adjustments such as picture size made correctly? (See pages 36, 38 and 39.)
<ul style="list-style-type: none"> Strange colour, light colour, or dark, or colour misalignment. 	<ul style="list-style-type: none"> Adjust the picture tone. (See pages 26 to 28 and 40.) Is the room too bright? The picture may look dark in a room that is too bright. Check the colour system setting. (See pages 22 and 41.) Check the input signal setting. (See pages 33 and 42.) Check the HDMI Setup setting. (See page 40.)
<ul style="list-style-type: none"> Power is suddenly turned off. 	<ul style="list-style-type: none"> The unit's internal temperature has increased. Remove any objects blocking vent or clean. Check the power control setting. (See page 30.) Is sleep timer set? (See page 17.)
<ul style="list-style-type: none"> No picture. 	<ul style="list-style-type: none"> Is connection to other equipment correct? (See pages 10 and 11) Has input signal setup been done correctly after connection? (See pages 33 and 42.) Is the correct input selected? (See page 42.) Is picture adjustment correct? (See pages 26 to 28.) Is the antenna connected properly? (See page 9.) Is "On" selected in "Audio Only"? (See page 40.)
<ul style="list-style-type: none"> No sound. 	<ul style="list-style-type: none"> Is the volume too low? (See page 17.) Make sure that headphones are not connected. (See page 12.)

Cautions regarding use in high and low temperature environments

- When the unit is used in a low temperature space (e.g. room, office), the picture may leave trails or appear slightly delayed. This is not a malfunction, and the unit will recover when the temperature returns to normal.
 - Do not leave the unit in a hot or cold location. Also, do not leave the unit in a location exposed to direct sunlight or near a heater, as this may cause the cabinet to deform and the LCD panel to malfunction.
- Storage temperature: -20°C to +60°C.

RS-232C port specifications

PC Control of the TV

- When a programme is set, the TV can be controlled from the PC using the RS-232C terminal.
The input signal (PC/video) can be selected, the volume can be adjusted and various other adjustments and settings can be made, enabling automatic programmed playing.
- Attach an RS-232C cable cross-type (commercially available) to the supplied Din/D-sub RS-232C for the connections.

NOTE

- This operation system should be used by a person who is accustomed to using PCs.

Communication conditions


Set the RS-232C communications settings on the PC to match the communications conditions of the TV. The communications settings of the TV are as follows:

Baud rate:	9,600 bps
Data length:	8 bits
Parity bit:	None
Stop bit:	1 bit
Flow control:	None

Communication procedure

Send the control commands from the PC via the RS-232C connector.
The TV operates according to the received command and sends a response message to the PC.
Do not send multiple commands at the same time. Wait until the PC receives the OK response before sending the next command.

Command format



Parameter

Input the parameter values, aligning left, and fill with space(s) for the remainder. (Be sure that four values are input for the parameter.)
When the input parameter is not correct, "ERR" returns. (Refer to "Response code format".)

0			
0	0	0	9
-	3	0	
1	0	0	
0	0	5	5

When "?" is input for some commands, the present setting value responds.

?			
?	?	?	?

Appendix

Response code format

Normal response



Return code (0DH)

Problem response

(communication error or incorrect command)



Return code (0DH)

Commands

- Commands not indicated here are not guaranteed to operate.

CONTROL ITEM	COMMAND	PARAMETER	CONTROL CONTENTS
POWER SETTING	P O W E R	0 _ _ _	POWER OFF (STANDBY)
INPUT SELECTION A	I T G D	_ _ _ _	INPUT SWITCHING (TOGGLE)
	I T V D	_ _ _ _	TV (CHANNEL FIXED)
	I A V D	* _ _ _	INPUT1 - 6 (1 - 6)
CHANNEL	D C C H	* _ _ _	TV DIRECT CHANNEL (1 - 99)
	C H U P	_ _ _ _	CHANNEL UP
	C H D W	_ _ _ _	CHANNEL DOWN
INPUT SELECTION B	I N P 1	0 _ _ _	INPUT1 (AUTO)
	I N P 1	1 _ _ _	INPUT1 (COMPONENT)
	I N P 1	3 _ _ _	INPUT1 (VIDEO)
	I N P 2	0 _ _ _	INPUT2 (AUTO)
	I N P 2	1 _ _ _	INPUT2 (COMPONENT)
	I N P 2	3 _ _ _	INPUT2 (VIDEO)
	I N P 3	0 _ _ _	INPUT3 (AUTO)
	I N P 3	2 _ _ _	INPUT3 (S-VIDEO)
	I N P 3	3 _ _ _	INPUT3 (VIDEO)
	I N P 6	0 _ _ _	AUTO
	I N P 6	5 _ _ _	DIGITAL
	I N P 6	6 _ _ _	ANALOGUE
AV MODE SELECTION	A V M D	0 _ _ _	TOGGLE
	A V M D	1 _ _ _	STANDARD
	A V M D	2 _ _ _	MOVIE
	A V M D	3 _ _ _	GAME
	A V M D	4 _ _ _	USER
	A V M D	5 _ _ _	DYNAMIC (Fixed)
	A V M D	6 _ _ _	DYNAMIC
	A V M D	7 _ _ _	PC

CONTROL ITEM	COMMAND	PARAMETER	CONTROL CONTENTS
VOLUME	V O L M	* _ _ _	VOLUME (0 - 60)
POSITION	H P O S	* _ _ _	H-POSITION (AV) (-10 - +10)
	H P O S	* _ _ _	H-POSITION (PC) (0 - 180)
	V P O S	* _ _ _	V-POSITION (AV) (-20 - +20)
	V P O S	* _ _ _	V-POSITION (PC) (0 - 100)
	C L C K	* _ _ _	CLOCK (0 - 180)
	P H S E	* _ _ _	PHASE (0 - 40)
	P H S E	* _ _ _	PHASE (0 - 40)
WIDE MODE	W I D E	0 _ _ _	TOGGLE (AV)
	W I D E	1 _ _ _	NORMAL (AV)
	W I D E	2 _ _ _	ZOOM 14:9 (AV)
	W I D E	3 _ _ _	PANORAMA (AV)
	W I D E	4 _ _ _	FULL (AV)
	W I D E	5 _ _ _	CINEMA 16:9 (AV)
	W I D E	6 _ _ _	CINEMA 14:9 (AV)
	W I D E	7 _ _ _	NORMAL (PC)
	W I D E	8 _ _ _	CINEMA (PC)
	W I D E	9 _ _ _	FULL (PC)
	W I D E	1 0 _ _	DOT BY DOT (PC)
MUTE	M U T E	0 _ _ _	TOGGLE
	M U T E	1 _ _ _	MUTE
	M U T E	2 _ _ _	MUTE OFF
SURROUND	A C S U	0 _ _ _	SURROUND TOGGLE
	A C S U	1 _ _ _	SURROUND ON
	A C S U	2 _ _ _	SURROUND OFF
AUDIO CHANGE	A C H A	_ _ _ _	TOGGLE
SLEEP TIMER	O F T M	0 _ _ _	OFF
	O F T M	1 _ _ _	SLEEP TIMER 30 MIN
	O F T M	2 _ _ _	SLEEP TIMER 1 HOUR
	O F T M	3 _ _ _	SLEEP TIMER 1 HOUR 30 MIN
	O F T M	4 _ _ _	SLEEP TIMER 2 HOUR
	O F T M	5 _ _ _	SLEEP TIMER 2 HOUR 30 MIN
TEXT	T E X T	0 _ _ _	TEXT OFF
	T E X T	1 _ _ _	TEXT ON (TOGGLE)
	D C P G	* _ _ _	DIRECT PAGE JUMP (100 - 899)

NOTE

- If an underbar (_) appears in the parameter column, enter a space.
- If an asterisk (*) appears, enter a value in the range indicated in brackets under CONTROL CONTENTS.

PC compatibility chart

	Resolution	Horizontal Frequency	Vertical Frequency	VESA Standard
VGA	720 × 400	31.5 kHz	70 Hz	
	640 × 480	31.5 kHz	60 Hz	✓
	640 × 480	37.9 kHz	72 Hz	✓
	640 × 480	37.5 kHz	75 Hz	✓
SVGA	800 × 600	35.1 kHz	56 Hz	✓
	800 × 600	37.9 kHz	60 Hz	✓
	800 × 600	48.1 kHz	72 Hz	✓
	800 × 600	46.9 kHz	75 Hz	✓

	Resolution	Horizontal Frequency	Vertical Frequency	VESA Standard
XGA	1024 × 768	48.4 kHz	60 Hz	✓
	1024 × 768	56.5 kHz	70 Hz	✓
	1024 × 768	60.0 kHz	75 Hz	✓
WXGA	1360 × 768	47.7 kHz	60 Hz	✓
SXGA	1280 × 1024	64.0 kHz	60 Hz	✓
SXGA+	1400 × 1050	65.3 kHz	60 Hz	✓

Specifications

Item			Model	LC-46G7M	LC-52G7M
LCD panel				46" (117 cm) Advanced Super View & BLACK TFT LCD	52" (132 cm) Advanced Super View & BLACK TFT LCD
Number of dots				6,220,880 dots (1920 × 1080 × 3 dots)	
Video Colour System				PAL/SECAM/NTSC 3.58/NTSC 4.43/PAL 60	
TV Function	TV-Standard			PAL: B/G, D/K, I SECAM: B/G, D/K, K/K ₁ NTSC: M	
	Receiving Channel	VHF/UHF		44.25-863.25 MHz	
		CATV		S1-S41ch (including Hyperband)	
	TV-Tuning System			Auto Preset 99 ch	
	STEREO/BILINGUAL			NICAM: B/G, I, D/K A2 stereo: B/G	
Brightness				450 cd/m ²	
Backlight life				60,000 hours (at Backlight Standard position)	
Viewing angles				H : 176° V : 176°	
Audio amplifier				15W × 2	
Speakers				Ø 6.5 cm 4pcs, Ø 2.0 cm 2 pcs	
Terminals	Rear	ANTENNA IN	75 Ω DIN type		
		INPUT 1	VIDEO in, AUDIO in, COMPONENT in (480I, 576I, 480P, 576P, 720P/50Hz, 720P/60Hz, 1080I/50Hz, 1080I/60Hz)		
		INPUT 2	VIDEO in, AUDIO in, COMPONENT in (480I, 576I, 480P, 576P, 720P/50Hz, 720P/60Hz, 1080I/50Hz, 1080I/60Hz)		
		INPUT 4	HDMI (HDMI input) (480I, 576I, 480P, 576P, 720P/50Hz, 720P/60Hz, 1080I/50Hz, 1080I/60Hz, 1080P/50Hz, 1080P/60Hz)		
		INPUT 5	HDMI (HDMI input) (480I, 576I, 480P, 576P, 720P/50Hz, 720P/60Hz, 1080I/50Hz, 1080I/60Hz, 1080P/50Hz, 1080P/60Hz), AUDIO in		
		INPUT 6	Ø 3.5 mm jack (Audio input), DVI-I (DVI-I input)		
		MONITOR OUT	VIDEO out, AUDIO out		
		RS-232C	9 pin D-sub male connector		
	Side	INPUT 3	VIDEO in, AUDIO in, S-VIDEO in		
Front	Headphones	Ø 3.5mm jack (Audio output)			
OSD language				English/Chinese/Arabic	
Power Requirement				AC 110-240 V, 50 Hz	
Power Consumption				262 W (0.9 W Standby)	287 W (0.9 W Standby)
Weight	Display only			30.5 kg	36.0 kg
	with Display and speakers			34.0 kg	40.0 kg
	with Display, speakers and stand			37.0 kg	43.0 kg
Operating Temperature				0°C - 40°C	

- As a part of policy of continuous improvement, SHARP reserves the right to make design and specification changes for product improvement without prior notice. The performance specification figures indicated are nominal values of production units. There may be some deviations from these values in individual units.

Optional accessories

The listed optional accessories are available for the LCD colour TV. Please purchase them at your nearest shop.

- Additional optional accessories may be available in the near future. When purchasing, please read the newest catalogue for compatibility and check the availability.

Part name	Model number
Wall mount bracket (for LC-46G7M/ LC-52G7M)	AN-52AG1
	AN-37AG2*

* You cannot change TV angles when you mount the TV on the wall using the AN-37AG2 wall mount bracket.

Removing the speakers


The unit's speakers can be attached and removed.

Before attaching/detaching the speakers

- Before detaching (or attaching) the speakers, unplug the AC cord from the AC outlet.
- Remove all terminal covers and connected cables.
- Make sure two or more people perform the operation when detaching (or attaching) the speakers.

1


Remove the two speaker terminal covers.



2

Unplug the speaker cables from the speaker terminals.


- Remove the speaker cables (②) while pushing in on the tabs on the speaker terminals (①).



3


Remove the two screws on both the left and right of the speaker unit.

- Place cushioning on both sides of the stand to avoid scratching or damaging to the speakers.



4

Lean the speakers slightly toward you (①) and lay them straight down onto the cushioning (②).



NOTE

- To attach the speakers, perform the steps in reverse order.
- External speakers can also be attached to the TV. (See page 32.)
- When the unit's speakers are already detached, the TV does not output volume unless external speakers are connected to the TV.


Dimensional drawings

LC-46G7M, LC-52G7M

Unit: mm


NOTE

- Figures within parentheses are for LC-52G7M.



CLEARING THE PASSWORD

If you forget the password, clear the password using the following procedure.




1

Press **MENU** to display the MENU screen, and then press ◀▶ to select "Setup".


2

Press ▲/▼ to select "Auto Installation", "Programme Setup", "Child Lock", and the password input screen displays.



3

Press and hold both **CH/▲** and **VOL+** on the TV simultaneously until the message appears on the screen.



The Password is

--	--	--	--

NOTE

- As a precautionary measure, make a note of your password above, scissor it from this manual, and keep it in a familiar place.

SHARP®

SHARP CORPORATION